

AGFA		V	mAh	passend für Kameras (ohne Gewähr)	27.03.08
NP-900		3,7	750	4Ti	
NP-40		3,7	1000	DC-735	
ACER					
NP-60 (NP-30)	8530A.001	3,7	1200	CR-5130, -6530, -8530	
NP-900		3,7	750	CS-5530, CS-6531-N	
ALDI / MEDION					
LI-40B/LI-42B		3,7	750	MD 85416	
DS8330		3,7	1200	Traveler DC 5300 / 5390 / 6300 / 8300 / 8600, MD 41856 / MD 85146,	
NP-900		3,7	750	Traveler DC-5080, DC 85700, Traveler Slimline x4, x5,x6, xs70, SuperSlim xs7	
SB-L110		7,4	1250	MD 9021/ 9021n/ 9035/ 9035n/ 9069/ 9069n/ 9090	
SB-L160		7,4	2000		
SB-L220		7,4	2500		
SB-L320		7,4	4000		
AIPTEK					
NP-60 (NP-30)		3,7	1200	Pocket DV 5700, 8700, T200, Z100pro, DDV-V1	
NP-120		3,6	1400	HDDV 8300	
AITO					
NP-60 (NP-30)		3,7	1200	23002	
AOSTA					
NP-60 (NP-30)		3,7	1200	DV 310	
NP-900		3,7	750	DA4092/ 5091/ 5092/ 5094/ DC E720 / Seelife Reefmaster	
AVANT					
NP-60 (NP-30)		3,7	1200	DC-530 STD/ S8	
NP-900	BATS4			S4/ S5 / S6	
BENQ					
NP-20		3,7	1000	T700, T800, X720, X725,X735, X800	
NP-40 F	DLI-102	3,7	1000	DC X-600 , E510 , E520 , E600 , P500	
NP-60 (NP-30)	C75A	3,7	1200	DC5330, DC C50, DC C60, S40	
NP-900		3,7	750	DC E43,E53, E720	
BRAUN					
NP-40F		3,7	1000	D808	
CANON					
NB-1LH		3,7	1000	Ixus V,V2,V3,300,330,400,430,500 PowerShot S100,S110,S200,S230,S300,S330,S399, S400, S410, S500,	
NB-2LH		7,4	800	PowerShot G7, S30,S40,S45,S50,S60, S70, S80 , EOS 350D, 400D	

CANON		V	mAh	passend für Kameras (ohne Gewähr)	16.04.08
NB-2L12H	BP-2L14	7,4	1300	Elura 40MC,50MC, 60,65,70,80,85,90, FVM30, FV 500, M20, M200, , IXYDV3, 5, 5BL, X20i,25i,200,200i,250i, FV500 MV5, 5i, 5iMC, 6iMC,51, MV51MC, MV790, 800,830(i) ,850(i), 880X,900,901,930,950,960, MVX 5i, 10i, 20(i), 30(i), 25(i), 30i, 35(i), 40, 45(i), MVX50(i), 200(i), 250(i) 300(i), 330(i), 350(i), 400(i), MVX400(i) - Optura 30,40, 50, 60,400, 500, PC 1018 ZR200,300,400, 500, 600, 700	
NB-3L		3,7	800	Ixus II, i, IIs, i5, 700, 750, 60, 65, PowerShot SD10, SD100	
NB-4L		3,7	1000	Ixus 30, 40, 50, 55, 60, 65, 70, 75, 80IS, 90IS, Ixus 500, i7, i zoom, Wireless, Powershot TX1	
NB-5H		6,0	1000	Powershot A5, A5 Zoom, A50, A520, 350, S10, 20	
NB-5L		3,7	800	Ixus 800IS, 850iS, 900Ti, 950 IS, 970IS Powershot SD 700	
NB-6L		3,7	750	Ixus 85 IS	
BP-208		7,4	1000	DC10, DC20, DC30, DC40	
BP-308		7,2	850	DC10, DC20, 21, 40, 100, MVX 1S, 4i, 450, 460, DVM5	
BP-315		7,2	1400	DC10, DC20, 21, 40, 100, MVX 1S, 4i, 450, 460, DVM5	
BP-511 (512/514)		7,4	1500	PowerShot G1,G2,G3,G4,G5,G6,Pro90,95,90IS Pro1 EOS 1D,D30,D60,10D,20D,20Da, 30D, 40D, 300D,5D,	
BP-522		7,4	2500	G-1,PV130,FV-Serie,MV-Serie,MVX-Serie, ZR-Serie,	
BP-535		7,4	3750	Optura 10,20,100,200, Pi, Xi	
LP-E5		7,4	1000	EOS 450D	
NP-E3		12,0	2400	EOS 1D Mark II, -1Ds, -1Ds, 1Ds Mark II	
CASIO					
NP-20		3,7	1000	Exilim EX23, EX-M1,M2,M20U, S1, S2, S3, S20U, S100, S500, S600, S600D, S770, S770D, S880 Exilim Z3,Z4, Z5, Z11, Z30,Z40, Z60,Z65, Z70, Z75, Exilim Z77, Z8	
NP-30C		3,7	1200	QV R3,R4, ,	
NP-40 C		3,7	1600	Exilim EX-Z30,Z40,Z50,Z55,Z57,Z500, Z600, Z700, Z750, Z850, Z1000, Z1050, Z1080, Z1200, EX-P505,P600,P700	
NP-50				Exilim HiZoom EX-V7	
NP-60C		3,7	800	S10, Z80, Z100, Z200	
NP-L7		3,7	800	QV-EX3	
CONCORD					
NP-60		3,7	1200	6340z	
DR-LB 4		3,7	800	4342z	
CREATIVE					
NP-60		3,7	1200	DiVi CAM 428	
ENNYAH					
NP-60		3,7	1200	DV320	

EPSON		V	mAh	passend für Kameras (ohne Gewähr)	16.04.08
SLB-1237		3,7		Photo PC L-500V	
EXAKTA/PRAK					
DR-LB 4		3,7	800	DC 4200	
FUJI					
NP-30 F		3,7	600	FinePix F440,450 NS	
NP-40 F	NP-40 NP-40N	3,7	1000	FinePix 402, A-470, A-700, F-455,- 460, -470, -480 FinePix -610, -650, F-700,-710, F-810, F-811, V10, FinePix Z1,Z1 Zoom, Z2, Z3, Z5fd	
NP-45		3,7	1000	Z10fd, Z100fd	
NP-50F		3,7	700	F50fd	
NP-60		3,7	1000	Finepix 50i, 401i, 601, F401,F402,F410,F450,F601Z, F700,. M 603	
NP-70	CGA-S005	3,7	1200	Finepix F20, F40fd, F47fd,	
NP-80		3,7	1300	Finepix 1300,1400, 4700,4800,4900,6800,6900, MX 1700, 2700,2900, 600Z	
NP-95		3,6	1800	Finepix F30, F31fd	
NP-120		3,6	1400	Finepix M603, F10, F11	
NP-140F		7,4	1050	FinePix S100fs	
NP-150 F		7,4	1500	FinePix S5 Pro	
FUJITSU-SIEME					
DR-LB 4		3,7	800	CX 431	
HITACHI					
CGA-DU14 CGA-DU21	DZ-BP07S DZ-BP14S DZ-BP21S	7,4	2200	DZ-MV350A / DZ-MV350E / DZ-MV380A DZ-MV380E / DZ-MV550A / DZ-MV580A	
CGR-D220 CGR-D320	DZ-BP16 DZ-BP28	7,2 7,2	1700 2500	AG-DVC15 DZ-MV200A / 200E / 208E / 230A / 230E / 250 / DZ-MV270A / 270E / PV-BP8 PV-DV100 / 100K / 200 / 200K / 400 / 400K / PV-DV600 / 600K / 700 / 710 / 800 / 800K / P8-A	
HP					
NP-60 (NP-30)	R07	3,7	1200	Photosmart R 507, 607, 707, 717, 725, 727,817, 818, R 837, 927, 937, 967	
JAY-Tech					
NP-40F		3,7	1000	I6550, Z630	
NP-60		3,7	1200	I6628	
JENOPTIK					
NP-40F		3,7	1000	JD 5.3z3 Easysshot, JD 7.3z3 Easysshot	
NP-60 (NP-30)	LP37	3,7	1200	JD 3.3 x 4ie, JD 5.2 z3 MPEG4, JD 6.0 z3 MPEG4	
JVC					
V428		7,4	3500	DV-Serie, DVL-Serie, GR-Serie	
KODAK					
DB-L 50	Klic 5001	3,7	1700	DX 6490, 7440, 7590, 7630, P712, 850, 880, Z730, 760, 7590	
NP-40F	Klic 7005	3,7	1000	C763	
NP-60 (NP-30)	Klic 5000	3,7	1200	LS 420,443 Zoom,633,663,743,753, EasyShare One, Z730, Z760, Z7590	
NP-80	Klic 3000	3,7	1300	DC 4500,4800, 4800EZ	

KODAK		V	mAh	passend für Kameras (ohne Gewähr)	16.04.08
Klic 5001		3,7	1700	Easyshare DX3600, 6490,7440,7590,7630, P712, EasyShare P850, P880, One, Z760, Z7590	
Klic 7000		3,7	800	Easyshare LS755 Zoom,	
Klic 7001		3,7	800	Easyshare V550, V570, V610, M753, M853, M863, M763, M893 IS	
Klic 7002		3,7	800	Easyshare V530, Z603	
KONICA-MINOL					
BP-800S	DR-LB1	3,6	800	KD 300Z	
DR-LB 4		3,7	800	KD 310Z, 400Z, 410Z, 420Z, 500Z, 510Z	
NP-1		3,7	820	X1	
NP-200		3,7	1100	Dimage X, Xi, Xt, Xt Biz, Xg, Z	
NP-400		7,4	2000	Dimage A1, A2, Dynax 5D, 7D	
DR-LB 4	NP500/600	3,7	800	Dimage G400, G500, G530, G600	
NP-700		3,7	700	Dimage X50, X60	
NP-800		7,4	700	Dimage A200	
NP-900		3,7	1000	Dimage E40, E50	
KYOCERA					
BP-780S		3,6	950	Finecam SL300R,400R , CONTAX SL300RT	
BP-800S BP-1000S	DR-LB1	3,6 3,6	1000	Finecam S, S3, S3L, S3R, S3U, S3x, S4, S5, S5R, S30, S40, S3300, ezdigital 1.3	
NP-900		3,7	750	EZ 4033	
LEICA					
NP-80		3,7	1300	Digilux Zoom	
BL-14	BP DC-1E	7,2	1700	Digilux 1, Digilux 2, Digilux 3	
BCA-7	BP-DC 2	3,7	650	D-Lux	
CGA-S005	BP-DC 4	3,7	1200	C-Lux , D-Lux 2, D-Lux 3	
CGA-S006		7,4	1200	V-Lux 1	
MAGINON					
NP-60 (NP-30)		3,7	1200	DC5300, DC-5390, DC-6300	
NP-900		3,7	1000	Slimline x4, x5, x6, x50, x60, Performic S5, S6	
MEDION					
DS8330		3,7	1200	Traveller 8300	
NP-40F	SLB-0837	3,7	1000	MD 85416, MD85562	
NP-60	DS8	3,7	1200	MD 41856, MD 85146, 88188 / Micromaxx MM 85085 Traveler DC-5300, DC-6300, DC-8300	
NP-900		3,7	1200	Traveler DC-85700	
SB-L110		7,4	1250	MD 9021,9021n,9035,9035n,9069,9069n,9090,	
SB-L160		7,4	2000	VP-D55, 65, 7L	
SB-L220		7,4	2500		
SB-L320		7,4	4000		
SB-LSM 80		7,4	1000	VP-D352i, VP-D353i, MD 9014	
MEGAPIX					
NP-40F		3,7	1000	LX 600, VX 600	
NP-60		3,7	1000	Vx8	
MINOX					
NP-60		3,7	1200	DC 1011, 1022, 8122, 5211, 8111	
NP-900		3,7	1000	DC 4211, 5222, 6311	

MUSTEK		V	mAh	passend für Kameras (ohne Gewähr)	16.04.08
NP-120		3,6	1400	MDC 6500 Z	
NIKON					
NP-60		3,7	1200	E880	
EN-EL1		7,4	800	Coolpix 775, 880, 885, 995, 4300, 4500, 4800, 5000, 5400, 5700, 8700, E880	
EN-EL2		3,7	1000	Coolpix 2500, 3500, SQ	
EN-EL3		7,4	1500	D70s, D80, D200,P3, P4	
EN-EL3e		7,4	1500	D50, D70, D80, D100, D200, D300	
EN-EL4		11,1	2000	D2H, D2HS, D2X, D2Xs	
EN-EL5		3,7	1100	Coolpix 3700, 4200, 5200, 5900, 7900, , Coolpix P4, P5000, P5100, P80 , S10	
EN-EL7		3,7	1100	Coolpix 8400, 8800	
EN-EL8		7,3	730	Coolpix S1, S2,S3, S5, , S6, 7c, S9 , S50c, S51c, S52 , Coolpix S52c , P1, P2,	
EN-EL9				D40, D40x, D60	
EN-EL10	NP-45F	3,6	1000	P50, S200, S210, S500, S510, S520, S600, S700,	
EN-EL11		3,7	650	Coolpix S550	
EN-4		7,2	2100	D1, D1X, D1H	
NYTECH					
NP-60		3,7	1200	ND-6360	
OLYMPUS					
NP-60	Li-20B	3,7	1200	AZ-1,AZ-2 Zoom, Ferrari Digital 2004	
Li-12B (Li-10B)		3,7	1400	C50, C60, C70 Zoom, C-5000, C470 Zoom, C760, C765 Ultra Zoom,C770 Movie, C770 Ultra Zoom, FE-190, FE-200, IR 500 mju 300 / 400 / 410 / 500 / 500Z / 600 / 725SW / 730 / 740 / 750 / 800 / 810 / 1000	
Li-30B		3,7	750	mju-mini Digital, Digital S	
Li-40B / Li42B	NP-50	3,7	1000	IR-300, FE-160, -150, -230, -240, -250, -5500, FE-280, -290, -300 mju 700, 720SW, 760, 770SW, 780, 790SW, 820, 830, mju 1000, 1200, SP-700,	
LI-50B		3,7	950	mju 850SW, 1020	
LI-63B	NP-45F	3,7	1000	Optio L30, M30, M40, T30, W30, V10	
BLM-1		7,4	1700	C5060, C7070, C8080 Wide Zoom, E 1, E3, E 300, E330, E500, E510	
BLS-1		7,2	1150	E400, E410, E420	
PANASONIC					
BC7		3,6	700	Lumix DMC-F7-A / K / N / R / S	
BCA-7	CGA-S001	3,7	650	Lumix DMC-F1, FX1, FX1EG-A,-R,-S, FX5EG-A,-S	
BM-7	CGA-S002	7,2	1400	DMC FZ-1,-1B, -2, -3. 4, 5,-10,-15,-20, FC20, C20	
BL14	CGR-S603	7,2	1700	Lumix DMC-LC1, LC5-K, LC5-S, LC40, L1	
CGA-S005	NP-70	3,7	1200	DMC-FX3, FX8, FX9, FX10, FX12, FX01,FX07, FX50, LX1, LX2	
CGA-S006	BMA7	7,4	1200	DMC-FZ4, FZ18, FZ5, FZ7, FZ8, FZ30, FZ50	
CGA-S007		3,7	1200	DMC-TZ1, TZ2, TZ3, TZ4, TZ5	
CGA-S008	BCE 10E	3,6	800	DMC FX30, FX33, FX35, FX55, FX100, FS3, FS5, DMC-FS20	

PANASONIC		V	mAh	passend für Kameras (ohne Gewähr)	27.03.08
CGR-D220 CGR-D320	D-16 D-18	7,2 7,2	1700 2500	NV-DA1 / 1B NV-DS1 / 3 / 8 / 11 / 12 / 15 / 25 / 27 / 28 / 29 / 30 / 33 / NV- DS 35 / 33 / 35 / 37 / 38 / 55 / 60 / 65 / 77 / 88 / 89 / NV-DS99 / 990 / NV-EX1 / 3 / 21 / NV-GS1 / 3 / 5 / 7 / 8 / 11 / 15 / NV- MX1 / 2 / 5 / 7 / 8 / 30 / 300 / 350 / 500,	
NP-40F	CGA-S004	3,7	1000	DMC-FX2, FX7,	
NP-60	CGA-S301	3,7	1200	SV-AV10-A/R/S, AS30 / AS3A /-AV-25, -AV30,-AV35,- AV100 / PT1	
CGA-DU14 CGA-DU21	CGA-DU07 CGA-DU14 CGA-DU21 VW- VBD070 VBD140 VBD210	7,4 7,4	1700 2200	NV-GS-Serie DZ-MV350A / DZ-MV380A, NV-GS10 / 11 / 22 / 27EG-S / 30 / 33 / 33EG-S / NV-GS37EG-S / 40 / 50 / 55B / 55EG-S / 55K / NV-GS65 / 70 / 75B/ S75EG-S / NV-GS100K / 120 / 120B / 120EG-S / 120K NV-GS150 / 150B / 150EG-S / 180 / NV-GS200 / 200K / 200B / 200EG-S / NV-GS250 / 250B / 250EG-S / 280 NV-GS300 / 400 / 400B / 400EG-S / 500 PV-GS19 / 31 / 33 / 35 / 50 / 50S / 55 / 65 / 70 / 75 / PV-GS120 / 150 / 180 / 200 / 250 / 400 VDR-D150 / D250 / D300 VDR-M30 / M50 / M50B / M50EG-S / M53 / M70/ 70B / VDR-M70EG-S / M75	
PENTAX					
EN-EL11	D-Li78	3,7	650	Optio V20	
NP-40F	D-Li8 D-Li68	3,7	1000	Optio A10, A20, A30, A40, L20, S, S4, S4i, S5i, S5n, Optio S5z, S6, S7, S10, S12, SV, SVi, T10, T20. X, Optio W10, W20, WP, Wpi, X	
NP-60F	D-Li2	3,7	1200	Optio 330, 330RS, 430, 430RS, 450, 550, 555,	
NP-120	D-Li7	3,6	1400	Optio 450,550,555,750z, MX, MX 4	
NP-400	D-Li50	7,4	2000	K10D	
NP-700	D-Li72	3,7	950	Optio Z10	
POLAROID					
NB-1LH		3,7	1000	PDC 5350	
NP-60		3,7	1200	PDC 3370	
PRAKTICA					
NP-40F	LB-5030	3,7	1000	Luxmedia 6105, 6403, 6503, 7105, 7203, 7303, 74,03	
NP-900		3,7	1000	Luxmedia 7103	
PREMIER					
NP-60 (NP-30)		3,7	1200	DS-8330, 8650	
NP-900		3,7	750	DS-4330, -4331,-4346, -5330, -5341, -6330, SL-6	
PROSIO					
NP-40F		3,7	1000	XT11600	
NP-60		3,7	1200	DS653 / Slim Neo XV6	
NP-900		3,7	1000	SlimNeo Xi, Xc 534	

REVUE		V	mAh	passend für Kameras (ohne Gewähr)	16.04.08
NP-40F		3,7	1000	DC 600 Slim, DC 5600 slim	
NP-60 (NP-30)		3,7	1200	DC5100, DC6200, DC8000	
NP-900		3,7	1000	DC 5 super slim, DC 6, DC 7, DC 50, DC 55 slim, DC 65 slim	
RICOH					
CGA-S005	DB-60	3,7	1200	R3, R4, R5, R30, R40, R50, GR digital, GX100	
CGA-S008	DB-70	3,6	800	R6, R7	
Klic 8000	DB-50	3,7	1800	R1, R1S, R1V, RZ1, R2	
NP-60F	DB-40	3,7	1200	RR10, RR30, GX100	
NP-80	DB-20L	3,7	1300	Caplio, RR1, RDC7, 6000, i500, RDC7s	
NP-120	DB-43	3,6	1400	RR30, Caplio G3, G4, G4 Wide, GX, GX8, 300G, 400G	
ROLLEI					
DR-LB 4		3,7	800	dt4000	
DS8330		3,7	1200	dp8300	
NP-40F		3,7	1000	da 10 , db 60, dp60, dx63, dx68, Tribute dt6	
NP-60 (NP-30)		3,7	1200	DT3200,DT4200, dp6000, dp6300, dp8330, DR-5100, DSX410, DK 3000	
NP-120		3,6	1400	DR-5100	
NP-900	C75X	3,7	1000	Prego dp4200, dp4220, dp5200, dp5700, dp6200, ds6	
SAMSUNG					
NP-40F	SLB-0737 SLB-0837	3,7 3,7	1000	Digimax i5, i50 MP3, 1, i70, L50, L60, L70, L73 ,L700 Digimax NV10, NV3, NV7 OPS, NV8, i85	
NP-60	SLB-1137	3,7	1200	Digimax U-CA 3,-CA4,-CA401,-CA5,-CA501,-CA505, V600, V700, V800	
NP-400	D-Li50	7,4	2000	GX-10	
NP-700	SLB-0637	3,7	950	L77	
SB-L110		7,4	1250	VP-SCD Serie , VP-D55,65,69,7L,	
SB-L160		7,4	2000	VP-L500Serie,	
SB-L220		7,4	2500	VP-M-Serie,	
SB-L360		7,4	4000		
SLB-0837(B)		3,7	650	Digimax NV8, NV10, NV15, NV20, L70, L83T	
SLB-0937		3,7	800	Digimax i8, L730, 830, NV4	
SLB-1137C		3,7	950	i7, L74 Wide	
SLB-1137D		3,7	950	i85, NV11, NV24 HD, NV30, NV40,	
SLB-1237		3,7	1200	Digimax L55, L55W, L85, L85W	
SLB-1437		3,7	1600	Digimax V3, V4, V5, V6, V50, V70	
SLB-1674		7,4	1500	GX 10, 20	
SLB-1974		7,4	1900	Pro815, Pro815SE	
SANYO					
Li-12B	DB-L10B	3,7	1400	DSC MZ 3,AZ 3, VPC-J1EX, J2EX	
DB-L20		3,7	850	DMC-C1, DSC-C4, -C5, -E6, -J4, VPC-CA6 Active, C4, -C40, -C5, -C6,-CG6, CG65, E7, VPC-J4EX, E6EX, E60	
DB L-40		3,7	1200	Xacti VPC-HD1A, HD1EX, HD2, FE30	
Klic 5001	DB-L50	3,7	1700	VPC HD1000	
NP-700	DB-L30	3,7	700	Xacti VPC-A5	
SEA & SEA					
NP-120		3,6	1400	DX-5000G, DX-8000G	

SEALIFE		V	mAh	passend für Kameras (ohne Gewähr)	27.03.08
NP-900		3,7	750	Reefmaster DC 500	
SHARP					
BP-800S	AD S 30 BT	3,6	800	AD-S30BT,S31BT,T50BT,T51BT,MD-MS701,702, 722, MD-MSH(S)2, MD-MT66,821,831	
SONY					
FR1		3,5	1600	DSC-F88, G1, M1, P100/LJ, P100/R, P100/S, P120, P150, P200, DSC-T30, T33, T50, V3	
FS10/11		3,6	1400	Hi8 CCD-CR1, DCR-TRV1VE, DCR-PC (MiniDV) Serie-PC1,2,3,3E,4,5,5E,6,9 DSC-F505, 505V,F55,55K,F55V, DSC-P1,P20,P30,P50,P55	
FT1		3,7	1200	DSC L1, DSC-T1, DSC-T10, DSC-T11, DSC-T3, DSC-T30, T33, DSC-T5, T9, DSC-M2	
NP-BD/FD1		3,6	900	DSC-T2, T300	
NP-BG1		3,6	900	DSC- H3, H7, H9,H10, H50, N1, N2, T20, T25, T70, DSC-T100, W30, W35, W40, W50, W55, W70, W80, DSC-W85, W90, W100, W110, W120, W130, W150, DSC-W170, W200, W300	
NP-FC10/11		3,7	1200	DSC F-77, FX-77, P2/3/4/5/6/7/8/9/10/12,-V1	
NP-FE1		3,7	1000	DSC T7	
NP-FF70		7,2	1400	DCR-IP5, TRV6E, IP220K	
NP-FM55H		7,4	1500	Alpha 100	
NP-FP50		7,4	1000	DCR-HC 18, 20, 40, 65, 85, DCR-DVD203, 403	
NP-FP70		7,4	1600	DCR-HC 18, 20, 40, 65, 85, DCR-DVD203, 403	
NP-FP90		7,4	2600	DCR-HC 18, 20, 40, 65, 85, DCR-DVD203, 403	
QM 51	NP-FM50	7,4	1800	Video Walkman GV-D1000, DSC-F707-F717, F828, R1, S30, S50, S70, S75 MVC-CD200, 250, 300, 400, 500	
QM 71	NP-FM70	7,2	2800	CCD-TRV (Hi8) Serien-TRV,6E,108,118,308,318,608, DCR-IP5, IP220K	
QM 91	NP-FM90	7,2	3900	DCR-Serie, DCS-Serie, M-Serie, CCD-TRV116,228,428,255,265,460	
STRATO					
NP-40F		3,7	1000	DC 2007	
TCM					
NP-900	C75C	3,7	1000	Digitalkamera 4,2Mio	
TOKIO					
NP-60		3,7	1200	DV 330	
TOSHIBA					
NP-60F	PDR-BT3	3,7	1200	PDR-DC5300, DC8300, -T20,-T30	
NP-80	PDR-BT1	3,7	1300	PDR-M3, M4,M5,M60,M70, M81	
BP-800S	PDR-BT9	3,6	800	PDR-MM3310,MS-702,MT821	
TRAVELER					
NP-60 (NP-30)		3,7	1200	DC 5300,5390, 6300 , 8300	
NP-900		3,7	750	DC5080, Slimline x4, x5, x6, xs70, Superslim xs7	
TRUST					
NP-60 (NP-30)		3,7	1200	922Z	
UFO					
NP-900		3,7	1000	DS5331, DS5080, DS5332	

VIVITAR		V	mAh	passend für Kameras (ohne Gewähr)	27.03.08
NP-60		3,7	1200	Cam-8300, VIVICAM 3930	
NP-900		3,7	750	VIVICAM 5340s	
VOIGTLÄNDER					
DS8330		3,7	1200	Virtus D8	
Li-30B		3,7	650	Vito 65	
NP-40F		3,7	1000	Vitolux XM 7.0	
NP-60		3,7	1200	D530, D630, D5300, D5390, D6300	
NP-900	C75C	3,7	1000	Virtus D4, D5, D6, D500, D600, S6	
YAKUMO					
NP-60		3,7	1200	Mega Image 34,37,47, 811x, CamMaster SD 482 Mega Image IV, VI, VII	
YASHICA					
NP-80		3,7	1300	Elite 3300	
NP-120	BP-1500S	3,6	1400	TVS Digital	